

# Installation.

V3.0, 2025

Soul Basin Mixer	p.2
Soul Extended Basin Mixer	p.2
Soul Sink Mixer	p.4
Soul Pull-Out Sink Mixer	p.6
Soul Wall/Bath Spout	p.10
Soul Wall Top Assembly (pr)	p.11
Soul Wall/Shower Mixer	p.12



**Products in this manual must by regulation be installed by licensed and registered trade people.**



## Water supply requirements


Not recommended for gravity fed water systems or water tanks.

**Working Pressure:** 350 – 500kpa (including cold and hot water pressure)

**Maximum Pressure:** 73psi / 500kpa


**Temperature Rating:** 5°C - 65°C (must not exceed 70°C)

Installation should comply with Australian standard AS/NZS 3500 or relevant local authority requirements.



**Soul.**  
& Soul Groove

## Soul Basin Mixer: Soul Extended Basin Mixer.



7	FLEXIBLE HOSE	2
6	LOCK NUT	1
5	GASKET	1
4	RUBBER WASHER	1
3	BRASS THREAD	1
2	O RING	1
1	MAIN BODY GROUP	1
NO #	NAME	QTY




### Before you start

Clean and flush out water supply pipes before installing any of our products to ensure there is no foreign matter in the pipes that could damage your tapware.

Before product installation, confirm whether the installation space meets the requirements according to the product specification drawings.

The installation platform must include a tap hole for the hob fixing of this product. Maximum platform thickness is 35mm.

**The tap hole required for the fixing of this product must be 33mm – 38mm**



## Main body installation

Soul Basin Mixer:  
Soul Extended Basin Mixer.

- UNPACK:** Remove the faucet from the packaging, rotate Lock Nut (6) anti-clockwise to remove from Brass Thread (3).
- GATHER:** Please ensure O-Ring (2), Rubber Washer (4) and Gasket (5) are also removed from Brass Thread (3) and placed in a safe place as they will be required for installation.
- SEAT:** Ensure the Brass Thread (3) is tightly fastened to the Main Body (1). Insert Main Body (1), Brass Thread (3) and O-Ring (2) into tap hole from the top. Correct the installation angle of the Main Body, most commonly facing the waste hole in the basin, then insert Rubber Washer (4), followed by Gasket (5) onto Brass Thread (3) from the underside of the top.
- FASTEN:** Fasten Lock Nut (6) onto Brass Thread (3) by turning it clockwise until all components (5), (4) and (2) are tightly locked to the Brass Thread, and the Main Body is firm. This will create a water-tight seal.

## Water connection



- INSERT:** Install Flexible Hoses (7) from the bottom of the Main Body (through centre of Brass Thread) and turn clockwise to hand tighten. Do not overtighten as this may cause the flexible hose to kink and limit or block the water supply or pressure.
- CONNECT:** Connect the Flexible Hoses to the hot and cold stop valves (water supply) and tighten clockwise with wrench. Ensure faucet lever is the closed position, turn on the hot and cold stop valves to ensure there are no water leaks from the stop valves or the Flexible Hoses.
- NOTE:** Make sure that the hot and cold Flexible Hoses are connected properly, with the hot on the left, and the cold on the right; when standing in front of the faucet.

## Seal test



- CLOSED:** Turn on the main water and rotate the cartridge in its closed position, between hot and cold connection (anti-clockwise/clockwise), testing the pressure resistance and sealing performance of the pipeline to ensure there are no water leaks.
- OPEN:** Open the cartridge (up direction), checking for any water leakage from the Main Body and the connections or cartridge. Leaking connections are not covered by the warranty, please check and re-fit accordingly.

## Soul Sink Mixer.



## Main body installation

## Soul Sink Mixer.

- UNPACK:** Remove the faucet from the packaging, rotate Lock Nut (6) anti-clockwise to remove from Brass Thread (3).
- GATHER:** Please ensure O-Ring (2), Rubber Washer (4) and Gasket (5) are also removed from Brass Thread (3) and placed in a safe place as they will be required for installation.
- SEAT:** Ensure the Brass Thread (3) is tightly fastened to the Main Body (1). Insert Main Body (1), Brass Thread (3) and O-Ring (2) into tap hole from the top. Correct the installation angle of the Main Body, most commonly facing the waste hole in the basin, then insert Rubber Washer (4), followed by Gasket (5) onto Brass Thread (3) from the underside of the top.
- FASTEN:** Fasten Lock Nut (6) onto Brass Thread (3) by turning it clockwise until all components (5), (4) and (2) are tightly locked to the Brass Thread, and the Main Body is firm. This will create a water-tight seal.

## Water connection


- INSERT:** Install Flexible Hoses (7) from the bottom of the Main Body (through centre of Brass Thread) and turn clockwise to hand tighten. Do not overtighten as this may cause the flexible hose to kink and limit or block the water supply or pressure.
- CONNECT:** Connect the Flexible Hoses to the hot and cold stop valves (water supply) and tighten clockwise with wrench. Ensure faucet lever is the closed position, turn on the hot and cold stop valves to ensure there are no water leaks from the stop valves or the Flexible Hoses.
- NOTE:** Make sure that the hot and cold Flexible Hoses are connected properly, with the hot on the left, and the cold on the right; when standing in front of the faucet.

## Seal test



- CLOSED:** Turn on the main water and rotate the cartridge in its closed position, between hot and cold connection (anti-clockwise/clockwise), testing the pressure resistance and sealing performance of the pipeline to ensure there are no water leaks.
- OPEN:** Open the cartridge (ON direction), checking for any water leakage from the Main Body and the connections or cartridge. Leaking connections are not covered by the warranty, please check and re-fit accordingly.

## Soul Pull-Out Sink Mixer: (with lead weight)



## Main body installation

Soul Pull-Out Sink Mixer:  
(with lead weight)

- UNPACK:** Remove the faucet from the packaging, rotate Lock Nut (6) anti-clockwise to remove from Brass Thread (3).
- SEAT:** Ensure the Brass Thread (3) is tightly fastened to the Main Body (1). Insert Main Body (1), Brass Thread (3) and O-Ring (2) into tap hole from the top. Correct the installation angle of the Main Body, most commonly facing the waste hole in the basin, then insert Rubber Washer (4), followed by Gasket (5) onto Brass Thread (3) from the underside of the top.
- FASTEN:** Fasten Lock Nut (6) onto Brass Thread (3) by turning it clockwise until all components (5), (4) and (2) are tightly locked to the Brass Thread, and the Main Body is firm. This will create a water-tight seal.

## Water connection


- INSERT:** Fasten Check Valve (9) with gasket provided onto extended spout inlet, then attach Extended Spray Hose (8) onto Check Valve (9). Fit supplied Weight onto Extended Spray Hose approx. 200mm from under bench (for spring-action model, please refer next page). Check that Pull-Out Spray Nozzle can extend to preference and without interference. Install Flexible Hoses (7) from the bottom of the Main Body. Do not overtighten as this may cause the flexible hose to kink and limit or block the water supply or pressure.
- CONNECT:** Connect the Flexible Hoses to the hot and cold stop valves (water supply) and tighten clockwise with wrench. Ensure faucet lever is the closed position, turn on the hot and cold stop valves to ensure there are no water leaks from the stop valves or the Flexible Hoses.
- NOTE:** Make sure that the hot and cold Flexible Hoses are connected properly, with the hot on the left, and the cold on the right; when standing in front of the faucet.

## Seal test




- CLOSED:** Turn on the main water and rotate the cartridge in its closed position, between hot and cold connection (anti-clockwise/clockwise), testing the pressure resistance and sealing performance of the pipeline to ensure there are no water leaks.
- OPEN:** Open the cartridge (ON direction), checking for any water leakage from the Main Body and the connections or cartridge. Leaking connections are not covered by the warranty, please check and re-fit accordingly.

## Soul Pull-Out Sink Mixer: (spring-action)



9	CHECK VALVE	1
8	SPRING LOADED HOSE	1
7	FLEXIBLE HOSE	2
6	LOCK NUT	1
5	GASKET	1
4	RUBBER WASHER	1
3	BRASS THREAD	1
2	O RING	1
1	MAIN BODY GROUP	1
NO #	NAME	QTY



## Main body installation

Soul Pull-Out Sink Mixer:  
(spring-action)

- UNPACK:** Remove the faucet from the packaging, rotate Lock Nut (6) anti-clockwise to remove from Brass Thread (3).
- SEAT:** Ensure the Brass Thread (3) is tightly fastened to the Main Body (1). Insert Main Body (1), Brass Thread (3) and O-Ring (2) into tap hole from the top. Correct the installation angle of the Main Body, most commonly facing the waste hole in the basin, then insert Rubber Washer (4), followed by Gasket (5) onto Brass Thread (3) from the underside of the top.
- FASTEN:** Fasten Lock Nut (6) onto Brass Thread (3) by turning it clockwise until all components (5), (4) and (2) are tightly locked to the Brass Thread, and the Main Body is firm. This will create a water-tight seal.

## Water connection


- INSERT:** Fasten Check Valve (9) onto extended spout inlet, then attach Spring Loaded Hose (8) onto Check Valve (9) by pressing the clip until it clicks. Check that Pull-Out Spray Nozzle can extend to preference and without interference. Install Flexible Hoses (7) from the bottom of the Main Body.
- CONNECT:** Connect the Flexible Hoses to the hot and cold stop valves (water supply) and tighten clockwise with wrench. Ensure faucet lever is the closed position, turn on the hot and cold stop valves to ensure there are no water leaks from the stop valves or the Flexible Hoses. Do not overtighten as this may cause the flexible hose to kink and limit or block the water supply or pressure.
- NOTE:** Make sure that the hot and cold Flexible Hoses are connected properly, with the hot on the left, and the cold on the right; when standing in front of the faucet.

## Seal test




- CLOSED:** Turn on the main water and rotate the cartridge in its closed position, between hot and cold connection (anti-clockwise/clockwise), testing the pressure resistance and sealing performance of the pipeline to ensure there are no water leaks.
- OPEN:** Open the cartridge (ON direction), checking for any water leakage from the Main Body and the connections or cartridge. Leaking connections are not covered by the warranty, please check and re-fit accordingly.

## Soul Wall/Bath Spout & Mini Wall Spout.




4	AERATOR	1
3	SPOUT	1
2	BACK PLATE	1
1	O-RING	1
NO#	DESCRIPTION	QTY



## Main body installation

- PREPARE:** Apply proper amount of PTFE TAPE on the threaded wall outlet.
- CONNECT:** Install Back Plate (2) and O-Ring (1) over Spout (3); allowing suitable working space.
- TRIM:** Gently slide Back Plate (2) against finished wall. The rubber O-ring will keep into place. The rear of the Back Plate can also be fixed with non-acidic silicone or double-sided adhesive.


## Wall Top Assembly (pair).




10	1/2 TURN CERAMIC SPINDLE	2
9	FIBRE WASHER	2
8	SPINDLE LOCK NUT	2
7	LARGE FLANGE O-RING	2
6	LOCK FLANGE	2
5	CUT-OFF GAUGE	2
4	HANDLE ADAPTOR	2
3	FLAT SCREW	2
2	HANDLE	2
1	GRUB SCREW	2
NO#	DESCRIPTION	QTY




Before you start



It is important to determine the finished wall depth for this product.  
The embedded depth distance recommended is 38mm - 65mm.



## Soul Shower/Wall Mixer.



### Before you start

Clean and flush out water supply pipes before installing any of our products to ensure there is no foreign matter in the pipes that could damage your faucet.


Before product installation, confirm whether the installation space meets the requirements according to the product specification drawings.

It is important to determine the finished wall depth for this product.

The embedded depth distance recommended is 40mm - 60mm.

### Main body installation

- CHECK:** Before installation, attach the threaded pipe connectors to the water inlet (5b) and ensure that the water inlet supply is at the same level to the wall.
- DEPTH:** Ensure that the Main Body (5) is properly secured in the wall, typically on a timber/metal noggin, through the mounting lugs and check that the depth is correct taking the finished wall into consideration.
- CONNECT:** Apply proper amount of PTFE TAPE on the inlet threaded pipe connector and connect hot and cold water supply (hot on the left, cold on the right, when viewed from operating position), or as marked on Main Body (5).



### Seal test

- CLOSED:** Turn on the main water, carefully remove the Cartridge Sheath (4) and rotate the cartridge in its closed position, between hot and cold connection (anti-clockwise/clockwise), testing the pressure resistance and sealing performance of the pipeline to ensure there are no water leaks.
- OPEN:** Using a 1/2" plug, plug the outlet of the Main Body (5a). Open the cartridge (up direction), checking for any water leakage from the Main Body and the connections.
- PROTECT:** After the Seal Test, please replace the Cartridge Sheath (4) and continue installation if there were no water leaks present. Leaking joints are not covered by the warranty.

### Embedding main body

- LEVEL:** Measure Main Body with parallel ruler to ensure it is perpendicular to the wall.
- CLEAR:** Ensure there is no rough concrete or tile glue/grout in contact with plated parts of the faucet allowing enough clearance and activity space for the handle wheel to manoeuvre.
- CONCEAL:** Finish tiles and grout.

### Trim installation

- FINALISE:** After tiling is complete, remove Cartridge Sheath.
- TRIM:** Install Back Plate (3), adjust to suitable position. The rear of the Back Plate can be fixed with non-acidic silicone or double-sided adhesive.
- COMPLETE:** Install handle (1) to the cartridge. Fasten Handle using Grub Screw (2) and Allen Key (6).

# Please do.



## Wipe, Rinse, Dry

Keep it simple for everyday cleaning.

Wipe gently with a warm and soapy damp cloth or sponge, using a mild detergent.

Rinse off with clean water.

Dry with a soft towel or microfiber cloth for an impeccable finish!

## For best results

For a deeper clean, be sure to regularly clean and remove limescale (that yucky white stuff that sometimes builds-up).

Apply a small amount of non-abrasive polish to a soft cloth and wipe to remove build up. Finish by completely wiping off the polish with a soft and clean, lint-free cloth.

We find a solution of 50:50 white vinegar and water also works wonders! Simply wipe with a soft cloth, rinse immediately and towel dry.

# Please don't.



## Avoid, Caution, Just Don't

Do not use any chemical cleaners. They contain nasty ingredients that can react and corrode the materials of the product.

Do not use 'Organic' or 'Natural' cleaning products as they often contain high concentrates of citric or lactic acid and limonene which may be harmful to the materials of the product.

Do not use abrasive cleaners, this can damage the surface of your product.

Do not use abrasive cloths, scrubbing brush or scourer to clean, this can scratch the surface of your product.

## Some more important stuff

Here is a list of ingredients to definitely avoid using:

Hydrochloric acid, formic acid, phosphorous acid, ammonium hydroxide, ethanol, benzine based ingredients or lactic acids and limonene (often found in natural cleaning products).


Residues of toiletries such as liquid soaps, shampoos and shower gels, hair dyes, perfumes, aftershave and nail varnish can also cause damage. Carefully rinse with water after use to remove residues. Likewise, do not store any cleaning agents or chemicals under the products, for example in a vanity unit, as the vapors may damage the products.



# Thanks for reading me!

## Flexible Connecting Pipes

Care must be taken when connecting the flexible connection pipes to the household pipework to ensure they do not bend sharply and kink or twist.



**⚠ Important:** Failure to follow these guidelines may result in poor performance and damage to the flexible connecting pipes.

# Warranty

Cartridge - 15 years

Body - 7 year warranty against manufacturing faults and flaking

Parts and Labour - 2 years

Commercial Use - 1 year

Accessories - 7 years

## Claim Procedure

For all warranty queries, please retain proof of purchase and contact place of purchase. These details can be found on your purchase invoice.

**Licensed plumbers installation invoice will also be required for warranty claims.**